

Firebird

Istruzioni di montaggio provvisorie Building manual is under construction

The model is completely finished, you just have to install your radio equipment and check for the CG being in the right place

Suggest wing servos : micro or submicro size with at least 2.0kg power and metal gear

The centre of gravity has to be located at about 65 to 68 mm from wing leading edge at the wing root. Feel free to move it a little forward or backward depending on your flying habits and need and in function of the motor you have installed.

Suggested travel value : (low rate/high rate)

Aileron : 10 mm upwards - 5mm downwards high rate , +8/-3 low rate

Elevator: 5 mm upwards - 5mm downwards high rate, +/- 3mm low rate

Again you may consider to modify these values according to your flying style.

Should you need further info and to receive the complete manual, write to info@fulcroservice.it

Il modello è praticamente pronto per l'installazione dei servi.

Usate servi con almeno 2kg di potenza, con gli ingranaggi in metallo, mini o micro per gli alettoni, micro per l'elevatore

Il baricentro deve cadere tra 65 e 68 mm dal bordo di entrata (vicino alla fusoliera).

Corse suggerite :

alettoni +10/-5 senza riduzione, +8/-3 con riduzione inserita

elevatore +5/-5 senza riduzione, +3/-3 con riduzione inserita

Per ulteriori informazioni e per ricevere il manuale definitivo, scrivete a info@fulcroservice.it

